

BUILT IN DESK BETWEEN WALLS

This is a really simple design, but most people don't consider using kitchen cabinets for something like this. This is perfect for a little nook in a bedroom, or a multi-purpose room where you don't want to have a desk sticking out. A few simple cabinets and you are ready to start paying bills, doing homework, or working on the computer.



Supplies You Will Need from the RTA Cabinet Store

- ✓ One 24" wide x 30" high wall cabinet (check to see if the cabinet style you choose has a center stile on the face frame, or if it is open face)
- ✓ Two 15" wide x 30" high wall cabinets
- ✓ One 21" drawer base cabinet
- ✓ One 8' piece of crown molding
- ✓ One straight valance
- ✓ One dishwasher end panel
- ✓ One piece of scribe molding
- ✓ One pint of stain



Instructions to Build a Built In Desk Between Walls

Step 1: Install the wall cabinets, securing them to the wall and to each other at the face frame.

Step 2: Install the drawer base cabinet.

Step 3: Install countertops. Once installed, take the straight valance and cut that to fit the space between the drawer base cabinet and the other wall (to create the false drawer look).

Step 4: Install crown molding.

Step 5: To create the same exact look as the picture, remove the door(s) of the center wall cabinet. Take the dishwasher end panel and cut it into pieces to fit under the first shelf (creating cubby holes for files/papers like the design picture has. To finish off the edging of the new pieces, you can either use the stain or cut the scribe molding into pieces that will cover them.

My Design Notes